

REVO C 1PH

	1	2	3	4	5	6		7	8	9	10	11	12	13	14	15	16
REVO C 1PH	R	C	1	-	-	-	-	-	-	-	-	-	-	-	-	-	-

ORDER CODE 30-800A:

CURRENT	FUSES	4	5	6	
description	description	code			note
30A	Extrarapid Fuse + Fuse Holder Included	0	3	0	
35A	Extrarapid Fuse + Fuse Holder Included	0	3	5	
40A	Extrarapid Fuse + Fuse Holder Included	0	4	0	
60A	Extrarapid Fixed Fuses Included	0	6	0	
90A	Extrarapid Fixed Fuses Included	0	9	0	
120A	Extrarapid Fixed Fuses Included	1	2	0	
150A	Extrarapid Fixed Fuses Included	1	5	0	
180A	Extrarapid Fixed Fuses Included	1	8	0	
210A	Extrarapid Fixed Fuses Included	2	1	0	
300A	Extrarapid Fixed Fuses Included	3	0	0	
400A	Extrarapid Fixed Fuses Included	4	0	0	
500A	Extrarapid Fixed Fuses Included	5	0	0	
600A	Extrarapid Fixed Fuses Included	6	0	0	
700A	Extrarapid Fixed Fuses Included	7	0	0	
800A	Extrarapid Fixed Fuses Included	8	0	0	5

MAX VOLTAGE	7	
description	code	note
480V	4	
600V	6	
690V	7	1,2

MAIN SUPPLY VOLTAGE	AUX VOLTAGE RANGE	8	
	V range	code	note
100/120Vac	90 to 135V Vac	1	3
200/208/230/240Vac	180 to 265V Vac	2	3
277Vac	238 to 330V Vac	3	3
380/415/480Vac	342 to 528V Vac	5	3
600Vac	540 to 759V Vac	6	3
690Vac	540 to 759V Vac	7	3

MAIN INPUT	9	
description	code	note
SSR	S	
0:20mA	B	
4:20mA	A	
0:10V	V	
10KPot	K	

FIRING	START OPTION	10	
description	description	code	note
Single Cycle	No Soft Start	C	
	Linear Soft Starter	S	
Half Cycle	No Soft Start	H	
	Linear Soft Starter	L	
	Soft Start for short Infr. Lamp	I	
Burst Firing	No Soft Start	B	
	Linear Soft Starter	J	
Phase Angle	No Soft Start	P	
	Linear Soft Starter	E	
Delayed Triggering	No Soft Start	D	
	Linear Soft Starter	T	
Zero Crossing	No Soft Start	Z	
	Linear Soft Starter	R	

Note (1): No cUL/UL approved **Note (2):** Available on unit ≥60A **Note (3):** Main Supply Voltage has to be included in Auxiliary Voltage range
Note (4): 24Vdc Backup Power for User Interface and Communications included **Note (5):** UL approved (not cUL)
Note (6): This configuration is possible only with Delayed Triggering or Phase Angle Firing **Note (7):** This configuration is possible only with Phase Angle Firing

Secondary Input can be configured for external current limit reference, external feedback or secondary input reference. See the manual for more informations.

ORDER CODE 1100-2100A:

CURRENT	FUSES	4	5	6	
description	description	code			note
1100A	Extrarapid Fixed Fuses Included	1	1	H	
1400A	Extrarapid Fixed Fuses Included	1	4	H	
1600A	Extrarapid Fixed Fuses Included	1	6	H	
1800A	Extrarapid Fixed Fuses Included	1	8	H	
2100A	Extrarapid Fixed Fuses Included	2	1	H	

MAX VOLTAGE	7	
description	code	note
480V	4	
600V	6	
690V	7	

AUX SUPPLY VOLTAGE	AUX VOLTAGE RANGE	8	
description	description	code	note
100/120Vac	90 to 135V Vac	1	
200/208/230/240Vac	180 to 265V Vac	2	

MAIN INPUT	9	
description	code	note
SSR	S	
0:20mA	B	
4:20mA	A	
0:10V	V	
10KPot	K	

FIRING	START OPTION	10	
description	description	code	note
Burst Firing	No Soft Start	B	
	Linear Soft Starter	J	
Phase Angle	No Soft Start	P	
	Linear Soft Starter	E	
Delayed Triggering	No Soft Start	D	
	Linear Soft Starter	T	
Zero Crossing	No Soft Start	Z	
	Linear Soft Starter	R	

CONTROL MODE	11	
description	code	note
Open Loop	0	
Voltage	U	
Voltage Square	Q	
Current	I	
Current Square	A	
Power Vxl	W	

Note (4): 24Vdc Backup Power for User Interface and Communications included
Note (5): This configuration is possible only with Delayed Triggering or Phase Angle Firing **Note (6):** This configuration is possible only with Phase Angle Firing

Secondary Input can be configured for external current limit reference, external feedback or secondary input reference. See the manual for more informations.

OPTIONS TABLE:

☐ No option ☒ Option selected (ex code 3: Logging + Totalizer)

I LIMIT	HB	BLUETOOTH	LOGGING	TOTALIZER	Cod. OPTION	NOTES
					Ø	<div>I LIMIT (CURRENT LIMIT) This option is used to keep the overcurrent inside set limit. It's necessary to drive primary transformers and cold resistance. It's dual limit for peak and RMS value.</div> <div>HB Alarm for partial or total load failure and Short Circuit on SCR (relay output)</div> <div>WiFi not available</div> <div>Bluetooth Communication and control of the unit via APP</div> <div>APP "RevoBLE" free download from Google Play or Apple Store</div> <div>Data Logger Reading and data logging of Current (I), Voltage (V) and Power (%) for diagnostics</div> <div>Energy Totalizer Power reading: totals the energy consumption of the load by providing the kW consumed</div>
					1	
					2	
					3	
					4	
					5	
					6	
					7	
					8	
					9	
					A	
					B	
					C	
					D	
					E	
					F	
					G	
					H	
					I	
					J	
					K	
					L	
					M	
					N	
					O	
					P	
					Q	
					R	
					S	
					T	
					U	
					V	