USER'S MANUAL

Rev. 07/2026

REVO S 3PH 690V

from 60A to 800A

018

M-RS3-60-800-690V



CD Automation S.r.l.
Via Picasso, 34/36 - 20025 Legnano (MI)- Italy
Tel. +39 0331 577479 - Fax +39 0331 579479
E-mail: info@cdautomation.com - Web: www.cdautomation.com

Declaration of conformity

Declaration of conformity CE

PRODUCT MANUFACTURER:

CD Automation S.R.L.
Controllers, Drives & Automation
Via Picasso, 34/36 - 20025 Legnano (MI)- Italy - P.I. 08925720156 -Tel. +39 0331 577479 - Fax +39 0331 579479
E-mail: info@cdautomation.com - Web: www.cdautomation.com

Declare that the product:

REVO S 3Ph 690V 60-800A

PRODUCT DESCRIPTION: Electric power control
SCOPE OF APPLICATION: Thermal control process

Applicable Directives:
2014/35/EU (Low Voltage "Safety" Directive)
2014/30/EU (Electromagnetic Compatibility "EMC" Directive)
2011/65/EU as amended by EU 2015/863 (RoHS Directives)

Applicable Standards:
Safety:
in conformity with directives:
EN 60947-1: 2021-10 Low Voltage Switchgear and Controlgear - Part 1: General Rules
EN 60947-4-3: 2024 Low Voltage Switchgear and Controlgear - Part 4-3: Contactors and motor-starters - AC semiconductor controllers and contactors for non-motor loads
as amended

EMC:
in conformity with directives:
EN IEC 61326-1: 2021/A11: 2026 Electrical equipment for measurement, control and laboratory use - EMC requirements - Part 1: General requirements
NOTE: EUT intended to be used on Industrial electromagnetic environment according to the standard above.
EN IEC 60947-1*: 2021 Par. 9.4 - Low-voltage switchgear and controlgear - Part 1: General rules
EN 60947-4-3*: 2024 Par. 9.4 - Low-voltage switchgear and controlgear - Part 4-3: Contactors and motor-starters - AC semiconductor controllers and contactors for non-motor loads
EN IEC 55011: 2025 - Industrial, scientific and medical equipment - Radio-frequency disturbance characteristics - Limits and methods of measurement
EN 55016-2-1: 2014 / A1: 2017 / AC: 2020 - Specification for radio disturbance and immunity measuring apparatus and methods - Part 2-1: Methods of measurement of disturbances and immunity - Conducted disturbance measurements
EN 55016-2-3: 2017 / A1: 2019 / A2: 2023 - Specification for radio disturbance and immunity measuring apparatus and methods - Part 2-3: Methods of measurement of disturbances and immunity - Radiated disturbance measurements
EN IEC 61000-4-2: 2025 - Electomagnetic compatibility (EMC) - Part 4-2: Testing and measurement techniques - Electrostatic discharge immunity test
EN IEC 61000-4-3: 2020 - Electromagnetic compatibility (EMC) - Part 4-3 : Testing and measurement techniques - Radiated, radio-frequency, electromagnetic field immunity test
EN 61000-4-4: 2012 - Electromagnetic compatibility (EMC) – Part 4-4: Testing and measurement techniques – Electrical fast transient/burst immunity test
EN 61000-4-5: 2014 / A1: 2017 - Electromagnetic compatibility (EMC) - Part 4-5: Testing and measurement techniques - Surge immunity test
EN IEC 61000-4-6: 2023 - Electromagnetic compatibility (EMC) - Part 4-6: Testing and measurement techniques - Immunity to conducted disturbances, induced by radio-frequency fields
EN 61000-4-8: 2010 - Electromagnetic compatibility (EMC) - Part 4-8: Testing and measurement techniques - Power frequency magnetic field immunity test
EN IEC 61000-4-11: 2020 / AC:2020 / AC: 2022 - Electromagnetic compatibility (EMC) – Part 4-11: Testing and measurement techniques – Voltage dips, short interruptions and voltage variations immunity tests

Environmental:
in conformity with directives:
EN IEC 63000[2]:2018- Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances (UE 2015/863 RoHS III) 10 of 10.
as amended

CAUTION:
1) This equipment is not intended for residential use and may not provide adequate protection against radio interference in such environments. In Class B environments, additional filtering on power lines is required. For Phase Angle control, further filtering is needed to meet Class A conducted emissions. Testing used a Schaffner FN2080-16-06; in the final application, a filter with equivalent attenuation and suitable for the operating current must be selected, or relaxed limits for loads over 20 kVA may be applied.
2) RoHS Compliance: Some components comply under the following exemptions: 6(c): Copper alloys containing up to 4% lead by weight (terminals). 7(a): Lead in high melting point solders within components (SCRs). 7(c)-i: Lead in glass in ceramic internal to components

Issued on: 08/05/2026

Sole Director and
Legal Representative
Simone Brizzi

Declaration of conformity

Declaration of conformity

UK CA

PRODUCT MANUFACTURER:

CD Automation S.R.L.
Controllers, Drives & Automation
Via Picasso, 34/36 - 20025 Legnano (MI)- Italy - P.I. 08925720156 -Tel. +39 0331 577479 - Fax +39 0331 579479
E-mail: info@cdautomation.com - Web: www.cdautomation.com

Declare that the product:

REVO S 3Ph 690V 60-800A

PRODUCT DESCRIPTION: Electric power control
SCOPE OF APPLICATION: Thermal control process

Applicable Directives:
2014/35/EU (Low Voltage "Safety" Directive)
2014/30/EU (Electromagnetic Compatibility "EMC" Directive)
2011/65/EU as amended by EU 2015/863 (RoHS Directives)

Applicable Standards:
Safety:
in conformity with directives:
EN 60947-1: 2021-10 Low Voltage Switchgear and Controlgear - Part 1: General Rules
EN 60947-4-3: 2024 Low Voltage Switchgear and Controlgear - Part 4-3: Contactors and motor-starters - AC semiconductor controllers and contactors for non-motor loads
as amended

EMC:
in conformity with directives:
EN IEC 61326-1: 2021/A11: 2026 Electrical equipment for measurement, control and laboratory use - EMC requirements - Part 1: General requirements
NOTE: EUT intended to be used on Industrial electromagnetic environment according to the standard above.
EN IEC 60947-1*: 2021 Par. 9.4 - Low-voltage switchgear and controlgear - Part 1: General rules
EN 60947-4-3*: 2024 Par. 9.4 - Low-voltage switchgear and controlgear - Part 4-3: Contactors and motor-starters - AC semiconductor controllers and contactors for non-motor loads
EN IEC 55011: 2025 - Industrial, scientific and medical equipment - Radio-frequency disturbance characteristics - Limits and methods of measurement
EN 55016-2-1: 2014 / A1: 2017 / AC: 2020 - Specification for radio disturbance and immunity measuring apparatus and methods - Part 2-1: Methods of measurement of disturbances and immunity - Conducted disturbance measurements
EN 55016-2-3: 2017 / A1: 2019 / A2: 2023 - Specification for radio disturbance and immunity measuring apparatus and methods - Part 2-3: Methods of measurement of disturbances and immunity - Radiated disturbance measurements
EN IEC 61000-4-2: 2025 - Electomagnetic compatibility (EMC) - Part 4-2: Testing and measurement techniques - Electrostatic discharge immunity test
EN IEC 61000-4-3: 2020 - Electromagnetic compatibility (EMC) - Part 4-3 : Testing and measurement techniques - Radiated, radio-frequency, electromagnetic field immunity test
EN 61000-4-4: 2012 - Electromagnetic compatibility (EMC) – Part 4-4: Testing and measurement techniques – Electrical fast transient/burst immunity test
EN 61000-4-5: 2014 / A1: 2017 - Electromagnetic compatibility (EMC) - Part 4-5: Testing and measurement techniques - Surge immunity test
EN IEC 61000-4-6: 2023 - Electromagnetic compatibility (EMC) - Part 4-6: Testing and measurement techniques - Immunity to conducted disturbances, induced by radio-frequency fields
EN 61000-4-8: 2010 - Electromagnetic compatibility (EMC) - Part 4-8: Testing and measurement techniques - Power frequency magnetic field immunity test
EN IEC 61000-4-11: 2020 / AC:2020 / AC: 2022 - Electromagnetic compatibility (EMC) – Part 4-11: Testing and measurement techniques – Voltage dips, short interruptions and voltage variations immunity tests

Environmental:
in conformity with directives:
EN IEC 63000[2]:2018- Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances (UE 2015/863 RoHS III) 10 of 10.
as amended

CAUTION:
1) This equipment is not intended for residential use and may not provide adequate protection against radio interference in such environments. In Class B environments, additional filtering on power lines is required. For Phase Angle control, further filtering is needed to meet Class A conducted emissions. Testing used a Schaffner FN2080-16-06; in the final application, a filter with equivalent attenuation and suitable for the operating current must be selected, or relaxed limits for loads over 20 kVA may be applied.
2) RoHS Compliance: Some components comply under the following exemptions: 6(c): Copper alloys containing up to 4% lead by weight (terminals). 7(a): Lead in high melting point solders within components (SCRs). 7(c)-i: Lead in glass in ceramic internal to components

Issued on: 08/05/2026

Sole Director and
Legal Representative
Simone Brizzi

Important warnings for safety

This chapter contains important information for the safety. The not observance of these instructions may result in serious personal injury or death and can cause serious damages to the Thyristor unit and to the components system included.
The installation should be performed by qualified persons.
In the manual are used symbols to give more evidence at the notes of safety and operativity for the attention for the user:

	This icon is present in all the operational procedures where the Improper operation may result in serious personal injury or death by Electrical Shock Hazard Symbol (a lightning bolt in a triangle) precedes an electric shock hazard CAUTION or WARNING safety statement.
	Warning or Hazard that needs further explanation than the label on unit can provide. Consult User's Guide for further information.
CE	Unit is compliant with European Union directives. See Declaration of Conformity for further details on Directives and Standards used for Compliance.
UL	If available, unit is a Listed device per Underwriters Laboratories. It has been investigated to ANSI/UL® 508 standards for Industrial Control Switches and equivalent to CSA C22.2 #14. For more detail search for File E231578 on www.ul.com
	Unit is compliant with applicable Australian regulatory requirements and bears the Regulatory Compliance Mark (RCM), based on compliance with EN 60947-4-3:2024.
	ESD Sensitive product, use proper grounding and handling techniques when installing or servicing product.
	Do not throw in trash, use proper recycling techniques or consult manufacturer for proper disposal.

A **"NOTE"** marks a short message to alert you to an important detail.

A **"CAUTION"** safety alert appears with information that is important for protecting your equipment and performance. Be especially careful to read and follow all cautions that apply to your application.

A **"WARNING"** safety alert appears with information that is important for protecting you, others and equipment from damage. Pay very close attention to all warnings that apply to your application.

Safety notes

WARNING! To avoid damage to property and equipment, injury and loss of life, adhere to applicable electrical codes and standard wiring practices when installing and operating this product. Failure to do so could result in damage, injury and death.

AVERTISSEMENT! Pour éviter d'endommager la propriété et l'équipement, les blessures et la perte de vie, respecter les codes électriques en vigueur et les pratiques de câblage standard au moment de l'installation et de l'utilisation de ce produit. Dans le cas contraire, cela peut entraîner la mort, des blessures graves ou des dommages.

WARNING! All service including inspection, installation, wiring, maintenance, troubleshooting, fuse or other user serviceable component replacement must be performed only by properly qualified personnel. Service personnel must read this manual before proceeding with work. While service is being performed unqualified personnel should not work on the unit or be allowed in the immediate vicinity.

AVERTISSEMENT! Tous les services, y compris l'inspection, l'installation, le câblage, l'entretien, le dépannage, le remplacement de fusibles ou d'autres composants pouvant être réparés par l'utilisateur, doivent être effectués uniquement par un personnel diment qualifié. Le personnel de service doit lire ce manuel avant d'effectuer tout travail. Pendant que l'entretien est exécuté, tout personnel non qualifié ne doit effectuer de travail sur l'appareil ni se trouver a proximité.

WARNING! When in use the power controller is connected to dangerous voltages. Do not remove the protective covers without first disconnecting and preventing power from being restored while servicing the unit.

AVERTISSEMENT! Au moment de l'utilisation, le régulateur de puissance est connecté a des tensions dangereuses. Ne retirer aucun couvercle de protection sans d'abord débrancher l'appareil et ainsi empêcher l'alimentation d'être rétablie pendant l'entretien.

WARNING! Do not use in aerospace or nuclear applications.

AVERTISSEMENT! Ne pas utiliser pour les applications aérospatiales ou nucléaires.

WARNING! The units are not developed to manage capacitive and inductive loads.

AVERTISSEMENT! Les unités ne sont pas développées pour la conduite de charges capacitives et inductives.

WARNING! The power controller's protection rating is IP20 with all covers installed and closed. It must be installed in an enclosure that provides all the necessary additional protections appropriate for the environment and application.

AVERTISSEMENT! L'indice de protection du régulateur de puissance est de IP20 lorsque les couvercles sont installés et fermés. L'appareil doit être installé dans une enceinte qui assure toute la protection supplémentaire nécessaire pour l'environnement et l'application.

WARNING! Ground the power controller via the provided protective earth grounding terminal. Verify ground is within impedance specifications. This should be verified periodically.

AVERTISSEMENT! Mise a la terre du régulateur de puissance par le biais de la borne de prise de terre de protection fournie. Vérifier que la prise de terre est conforme aux spécifications de l'impédance. Cela doit être vérifié périodiquement.

WARNING! Electric Shock Hazard: when the power controller has been energized, after shutting off the power, wait at least one minute for internal capacitors to discharge before commencing work that brings you in to contact with power connections or internal components.

AVERTISSEMENT! Risque de décharges électriques: lorsque le régulateur de puissance est mis sous tension, après avoir été éteint, attendre au moins une minute pour que les condensateurs internes se déchargent avant de commencer tout travail incluant le contact avec les connexions électriques ou les composants internes.

WARNING! The installation must be protected by electromagnetic circuit breakers or by fuses. The semiconductor fuses located inside the power controller are classified for UL as supplementary protection for semiconductor devices. They are not approved for branch circuit protection.

AVERTISSEMENT! L'installation doit être protégée par des disjoncteurs électromagnétiques ou des fusibles. Les fusibles pour semi-conducteurs situés a l'intérieur du régulateur de puissance sont classés UL comme protection supplémentaire pour les dispositifs pour semi-conducteurs. Ils ne sont pas approuvés pour la protection des circuits de dérivation.

WARNING! When making live voltage or current measurements, use proper personal protective equipment for the voltages and arc-flash potentials involved.

AVERTISSEMENT! Au moment de relever des mesures de tension ou de courant en direct, utiliser un équipement de protection individuelle approprié pour les tensions et les potentiels d'arc électrique concernés.

WARNING! Verify the voltage and current ratings of the power controller are correct for the application.

AVERTISSEMENT! Vérifier que les valeurs de tension et de courant du régulateur de puissance sont correctes pour l'application.

CAUTION: To avoid compromising the insulation, do not bend wire or other components beyond their bend radius specifications.

ATTENTION: Pour éviter de compromettre l'isolation, ne pas plier le fil ou tout autre composant au-delà de ses spécifications en matière de rayon de courbure.

CAUTION: Protect the power controller from high temperature, humidity and vibrations.

ATTENTION: Protéger le régulateur de puissance contre les températures élevées, l'humidité et les vibrations.

CAUTION: The power controller warranty is void if the tested and approved fuses are not used.

ATTENTION: La garantie du régulateur de puissance est nulle si aucun fusible testé et approuvé n'est utilisé.

CAUTION: Only trained and authorized personnel should access and handle the internal electronics and they must follow proper electro-static prevention procedures.

ATTENTION: Seul le personnel formé et autorisé peut accéder aux composants électroniques internes et les gérer, et il doit se conformer a des procédures de prévention électrostatique appropriées.

CAUTION: Install an appropriately sized RC filter across contactor coils, relays and other inductive loads.

ATTENTION: Installer un filtre RC de dimensions appropriées sur les bobines du contacteur, les relais et autres charges par induction.

CAUTION: The thyristor units here described have been designed for use with sinusoidal networks with nominal frequency 50-60 Hz. Any application with NON-SINUSOIDAL, distorted or disturbed networks could compromise the correct operation of the unit.

ATTENTION: Les unités de thyristors décrites ici ont été conçues pour être utilisées avec des réseaux sinusoïdaux d'une fréquence nominale de 50 à 60 Hz. Toute application utilisant des réseaux NON SINUSOÏDAUX, déformés ou perturbés peut compromettre le bon fonctionnement de l'appareil.

NOTE: Provide a local disconnect to isolate the power controller for servicing.

REMARQUE: Fournir une déconnexion locale afin d'isoler le régulateur de puissance pour l'entretien.

NOTE: The nominal current is specified for ambient temperatures at or below 40˚ C. Ensure the application design allows for adequate cooling of each power controller. The power controller must be mounted vertically. The cooling design must prevent air heated by one power controller from causing power controllers mounted above to exceed the ambient operating temperature limit. When power controllers are mounted side by side allow a minimum spacing of 15mm between them.

REMARQUE: Le courant nominal est précisé pour des températures ambiantes égales ou inférieures a 40˚C. S'assurer que la conception de l'application permette le refroidissement adéquat de chaque régulateur de puissance. Le régulateur de puissance doit être monté verticalement. La conception de refroidissement doit empêcher l'air chauffé par le régulateur de puissance de dépasser la limite de température de fonctionnement ambiante de la part des régulateurs de puissance montés au-dessus. Lorsque les régulateurs de puissance sont montés côte a côte, il faut conserver un espacement minimal de 15 mm entre les deux.

NOTE: Use only copper cables and wires rated for use at 75˚C or greater.

REMARQUE: N'utiliser que des cables et des fils en cuivre pour l'utilisation a 75˚C ou plus.

Maintenance

In order to have a corrected cooling, the user must clean the heat-sink and the protective grill of the fans. The frequency of this servicing depends on environmental pollution.
Also check periodically if the screw for the power cables and safety earth are tightened correctly (See Connection Diagram).

Warranty condition

Producer gives a 12 months warranty to its products.

The warranty is limited to repairing and parts substitution in our factory and does exclude products not properly used and fuses.

Warranty does not include products with serial numbers deleted. The faulty product should be shipped to Producer at customer's cost and our Service will evaluate if product is under warranty terms.

Substituted parts remain of Producer property.

CE

CD Automation srl assumes no liability for any damage to persons or property deriving from tampering, from incorrect or improper use, or from any use not conforming to the characteristics of the controller and to the instructions in this User Manual.
General terms and conditions

Return Material Authorization (RMA)

Customers wishing to return any items, whether they are incorrectly supplied, faulty or damaged in transit, must first complete a Return Material Authorisation (RMA) form to obtain an RMA number from the Service Department.
A full repair service is available for customers. Prior to submitting the RMA form and returning products, customers are recommended to contact the technical support team to determine whether the issue can be resolved with telephone support.

How the RMA service works

The RMA form and details are available on our web sites:

https://www.cdautomation.com/rma-english-version/

When completing the RMA form, please be as specific as possible about the problem, including any pertinent application details. The more information given, the more quickly and more thoroughly the problem can be solved. The minimum information required is:

1. The Full Model Number
2. Quantity of units being returned
3. The units Serial Number(s)
4. A description of the problem ("faulty" or "unknown" is not sufficient)

Summary

Declaration of conformity . . . 3

Important warnings for safety . . . 4

Maintenance . . . 7

1 Basic Connections and sizing . . . 10

2 Identification and Order Code . . . 11

2.1 Identification of the unit . . . 11

2.2 Order Code . . . 12

3 Technical Specifications . . . 13

3.1 General features . . . 13

3.2 Input features . . . 13

3.3 Output features (power device) . . . 13

3.4 Fan Specification . . . 14

3.5 Environmental installation conditions . . . 14

3.6 Derating Curve and Thermal conditions . . . 14

6.7 Calculating flow capacity of the fan . . . 15

4 Installation . . . 16

4.1 Dimensions and weight . . . 17

4.2 Fixing holes . . . 18

5 Wiring instructions . . . 19

5.1 Removing the cover . . . 19

5.2 Line power and Load cable/bar dimensions and torque (suggested) . . . 19

5.3 Cable dimensions (suggested) of Earth and of the Command Terminals . . . 20

5.4 Terminals Positions . . . 21

5.5 Power Terminals . . . 22

5.6 Control Terminals . . . 24

5.7 Schematic . . . 25

5.8 Connection Diagram for 3 phases . . . 27

6 Led status and alarms 28
7 Heater Break alarm and SCR short circuit 29
7.1 Heater break Calibration procedure 29
8 Input Setting 30
9 Burst Firing settings 31
10 Firing type 32
10.1 Zero Crossing 32
10.2 Burst Firing 32
11 Supply the electronic board 33
12 Internal Fuse 34

1 Basic Connections and sizing

Star wiring with resistive load (control on three phases with REVO S-3PH)

$$I = \frac{P}{1{,}73V}$$

V = Nominal voltage of the load
I = Nominal current of the load
P = Nominal power of the load



Star wiring with resistive load + Neutral (control on three phases with REVO S-3PH)

$$I = \frac{P}{1{,}73V}$$

V = Nominal voltage of the load
I = Nominal current of the load
P = Nominal power of the load



Delta wiring with resistive load (control on three phases with REVO S-3PH)

$$I = \frac{P}{1{,}73V}$$

V = Nominal voltage of the load
I = Nominal current of the load
P = Nominal power of the load



Open Delta wiring with resistive load (control on three phases with REVO S-3PH)

$$I = \frac{P_{tot}}{3V}$$

V = Nominal voltage of the load
I = Nominal current of the load
P = Nominal power of the load



2 Identification and Order Code

2.1 Identification of the unit

Caution: Before to install, make sure that the Thyristor unit have not damages. If the product has a fault, please contact the dealer from which you purchased the product.

The identification's label give all the information regarding the factory settings of the Thyristor unit, this label is on the unit, like represented in figure.
Verify that the product is the same thing as ordered.

The units are delivered already configured and ready to use in line with the order code.

2.2 Order Code

	1	2	3	4	5	6		7	8	9	10	11	12	13	14	15	16
REVO S 3PH	R	S	3	_	_	_	-	_	_	_	_	_	_	_	_	_	_

CURRENT	FUSES	4	5	6
description	description	code		
60A	Fixed Fuses Included	0	6	0
90A	Fixed Fuses Included	0	9	0
120A	Fixed Fuses Included	1	2	0
150A	Fixed Fuses Included	1	5	0
180A	Fixed Fuses Included	1	8	0
210A	Fixed Fuses Included	2	1	0
300A	Fixed Fuses Included	3	0	0
350A	Fixed Fuses Included	3	5	0
400A	Fixed Fuses Included	4	0	0
450A	Fixed Fuses Included	4	5	0
500A	Fixed Fuses Included	5	0	0
800A	Fixed Fuses Included	8	0	0

MAX VOLTAGE	7
description	code
480V	4
600V	6
690V	7

VOLTAGE SUPPLY AUX		8
Main Supply Voltage	Aux Voltage Range	code
100/120Vac	90 to 135V Vac	1
200/208/230/240Vac	180 to 265V Vac	2
277Vac	238 to 330V Vac	3
380/415/480Vac	342 to 528V Vac	5
600Vac	540 to 759V Vac	6
690Vac	540 to 759V Vac	7

INPUT	9
description	code
SSR	S
0:10V	V
4:20mA	A

FIRING	10
description	code
Zero Crossing	Z
Burst Firing 4 Cycles On at 50% Power Demand	4
Burst Firing 8 Cycles On at 50% Power Demand	8
Burst Firing 16 Cycles On at 50% Power Demand	6

CONTROL MODE	11
description	code
Open Loop	0

FUSES & OPTION	12
description	code
Fixed Fuses Std for all Units > 40A	F
Fixed Fuses Std + CT + HB	H

FAN VOLTAGE	13
description	code
Fan 115Vac Option	1
Fan 230Vac Std Version	2
Fan 24Vdc Option	3

APPROVALS	14
description	code
CE EMC For European Market	0

MANUAL	15
description	code
None	0
Italian	1
English	2
German	3
French	4

VERSION	16
description	code
Std version	1
High Sensitivity HB below 5A	5

Note: The 690V unit is available with CE Only

3 Technical Specifications

3.1 General features

Operative voltage: 690V +10% max -10% min
Cover and Socket material: PolymericV2
Utilization Category: AC-51 AC-55b
IP Code: 20
Method of Connecting: Load in Delta, Load in Star
Auxiliary voltage:
Order code RS3_ _ _ -_1 = line voltage 100/120V transformer range 90:135V (8 VA Max)
Order code RS3_ _ _ -_2 = line voltage 200/208/220/230/240V transformer range 180:265V (8 VA Max)
Order code RS3_ _ _ -_3 = line voltage 277 transformer range 238:330V (8 VA Max)
Order code RS3_ _ _ -_5 = line voltage 380/400/415/440/480V transformer range 342:528V (8 VA Max)
Order code RS3_ _ _ -_6 = line voltage 600V transformer range 540:759V (8 VA Max)
Order code RS3_ _ _ -_7 = line voltage 690V transformer range 540:759V (8 VA Max)
Relay output for Heater Break Alarm (only with HB option): 0.5A a 125VAC

3.2 Input features

Analogic input: 0 ÷ 10Vdc impedance 15 kΩ
Analogic input: 4 ÷ 20mA impedance 100 Ω
POT: 10 kΩ min.
Digital Input: 4 ÷ 24Vdc 5mA Max (ON ≥4Vdc OFF <1Vdc)
3hz Max duty cycle min. 100 ms

3.3 Output features (power device)

Current	Nominal Voltage range (Ue)	Repetitive peak reverse voltage (Uimp)		Latching current	Max peak one cycle	Leakage current	FUSE I^2t value Suggested A2s (at690V)	Frequency range	Power loss Thyristor + Fuse	Isolation Voltage (Ui)
(A)	(V)	(480V)	(690V)	(mAeff)	(10msec.) (A)	(mAeff)	tp=10msec	(Hz)	I=Inom (W)	Vac
60A	24÷690	1600	1800	600	1900	15	16940	47÷70	290	3000
90A	24÷690	1600	1800	600	1900	15	16940	47÷70	580	3000
120A	24÷690	1600	1800	600	1900	15	16940	47÷70	598	3000
150A	24÷690	1600	1800	400	1900	15	27500	47÷70	594	3000
180A	24÷690	1600	1800	400	1900	15	48400	47÷70	740	3000
210A	24÷690	1600	1800	400	1900	15	84700	47÷70	898	3000
300A	24÷690	1600	1800	400	1900	15	79750	47÷70	1324	3000
350A	24÷690	1600	1800	400	1900	15	79750	47÷70	1324	3000
400A	24÷690	1600	1800	200	7820	15	236500	47÷70	1439	3000
450A	24÷690	1600	1800	200	7820	15	462000	47÷70	1641	2500
500A	24÷690	1600	1800	200	7820	15	462000	47÷70	2096	3000
800A	24÷690	1600	1800	200	7820	15	387200	47÷70	1753	3000

3.4 Fan Specification

Size		Number of fans 230Vac Standard	Number of fans 115Vac Option	Number of fans 24Vdc Option
S11	60A, 90A	One Fan - 16W	One Fan - 14W	One Fan - 7W
S13	120A, 150A, 180A, 210A	Two Fans - (16W x 2) 32W	Two Fans - (14W x 2) 28W	Two Fans - (7W x 2) 14W
S14	350A, 450A	Two Fans - (16W x 2) 32W	Two Fans - (14W x 2) 28W	Two Fans - (7W x 2) 14W
S14	300A, 400A, 500A	Four Fans - (16W x 4) 64W	Four Fans - (14W x 4) 56W	Four Fans - (7W x 4) 28W
S17	800A	Six Fans - (16W x 6) 96W	Six Fans - (14W x 6) 84W	Six Fans - (7W x 6) 42W

3.5 Environmental installation conditions

Surrounding temperature	-5°C to 40°C (23-104°F) at nominal current. Over 40°C (104°F) use the derating curve (max 50°C).
Storage temperature	-25°C to 70°C -13°F to 158°F
Installation place	Don't install at direct sun light, where there are conductive dust, corrosive gas, vibration or water and also in salty environmental.
Altitude	Up to 1000 meter over sea level. For higher altitude reduce the nominal current of 2% for each 100m over 1000m
Humidity	From 5 to 95% without condense and ice
Pollution Level	Up to 2nd Level ref. IEC 60947-1 6.1.3.2

3.6 Derating Curve and Thermal conditions

The nominal current of the units in specification are referred to continuos service at 40°C ambient temperature. For higher temperature multiply the nominal current times derating coefficient K here represented:



Operation at ambient operating temperature above 40°C not covered by UL®

6.7 Calculating flow capacity of the fan

All the thyristor units when are in conduction produces power loss that is dissipated inside cubicle in terms of heating. Due to this fact the internal temperature of cubicle is higher than ambient temperature. To be cooled the thyristor need of fresh air cooling and to do it is normally used a fan mounted on the front door or on the roof of the cabinet.

Procedure to size Fan air mass flow (V): see power loss for each thyristor and fuse mounted indicated in the manual related to the current (Output feature and Internal fuse Chapter)

$V = f * \frac{Qv}{tc-ta}$	**Qv** = total power losses (w) (thyristor + fuse power loss) **ta** = ambient temperature (°C) **tc** = cabinet temperature (°C) **V** = fan air mass flow (m3/h) **f** = altitude coefficient (see table on right)	**Altitude** 0:100 meters f = 3.1 m3k/Wh 100:250 meters f = 3.2 m3k/Wh 250:500 meters f = 3.3 m3k/Wh 500:750 meters f = 3.4 m3k/Wh

The formulas used are for information only and is not a substitute for a proper thermal rating done by a qualified person.

4 Installation

Before to install, make sure that the Thyristor unit have not damages.
If the product has a fault, please contact the dealer from which you purchased the product. Verify that the product is the same thing as ordered.
The Thyristor unit must be always mounted in vertical position to improve air cooling on heat-sink.
Maintain the minimum distances (*) in vertical and in horizontal as represented, *this area must be free from obstacle* (wire, copper bar, plastic channel).
When more unit has mounted inside the cabinet maintain the air circulation like represented in figure without obstacle for the air flow.Is necessary to install a fan to have better air circulation as calculated previously.



The V Air flow must be equal or more than the value calculated.

If the cabinet fan mounted by the customer have an air flow lower than the correct value the warranty will decay.

4.1 Dimensions and weight

REVO-S 3PH
60A÷90A (S11)
W 137mm - H 440mm - D 270mm
Weight 10,5 kg

REVO-S 3PH
120A÷210A (S13)
W 262mm - H 440mm - D 270mm
Weight 20 kg

REVO-S 3PH
300A÷500A (S14)
W 262mm - H 520mm - D 270mm
Weight 28 kg

REVO-S 3PH
800A (S17)
W 411mm - H 560mm - D 270mm
Weight 51,6 kg

4.2 Fixing holes

REVO-S 3PH
60A÷90A (S11)



REVO-S 3PH
120A÷210A (S13)



REVO-S 3PH
300A÷500A (S14)



REVO-S 3PH
800A (S17)



5 Wiring instructions

The Thyristor unit could be susceptible to interferences lost by near equipments or by the power supply, for this reason in accord to the fundamental practices rules is opportune take some precautions:

- The coil contactor, the relays and other inductive loads must be equipped with opportune RC filter.
- Use shielded bipolar cables for all the input and output signals.
- The signal cables must not be near and parallel to the power cables.
- Local regulations regarding electrical installation should be rigidly observed.

Use 75°C copper (CU) conductor only or use copper bus bars sized for field wiring connection, wire ranges (AWG), wire terminal type (ZMVV), tightening torque in the tables below.

5.1 Removing the cover

Instructions for open the thyristor unit

5.2 Line power and Load cable/bar dimensions and torque (suggested)

Current	Connector Type	Torque		Cable			Cable Terminal	Bar
		Lb-in	Nm	AWG	mm²	kcmil		
60A (S11)	Screw M8	177	20.0	5	16	33.1	UL Listed (ZMVV) Copper Tube Crimp. Lug	-
90A (S11)		177	20.0	3	25	52.6		-
120A (S13)		177	20.0	2	35	66.4		-
150A (S13)		177	20.0	0	50	106		-
180A (S13)		177	20.0	00	70	133		-
210A (S13)		177	20.0	000	90	168		-
300A (S14)	Power field wiring Bus Bar with M10 screw	265	30.0	2 x 1/0	2 x 70	350		Bus bar 30x5 mm
350A (S14)		265	30.0	2 x 1/0	2 x 70	500		Bus bar 30x5 mm
400A (S14)		265	30.0	2 x 3/0	2 x 95	600		Bus bar 30x5 mm
450A (S14)		265	30.0	2 x 4/0	2 x 95	700		Bus bar 66x6 mm
500A (S14)		265	30.0	-	2 x 150	2x250 900		Bus bar 66x6 mm
800A (S17)		265	30.0	-	2 x 300	2x500		Bus bar 66x6 mm

Bus bar	2PH 300÷400A	2PH 450÷800A



5.3 Cable dimensions (suggested) of Earth and of the Command Terminals

Current	Earth			Command Terminals	
	Cable		Screw	Cable	
	mm²	AWG	M	mm²	AWG
60A (S11)	16	6	M8	0,50	18
90A (S11)	16	6	M8	0,50	18
120A (S13)	16	6	M8	0,50	18
150A (S13)	25	4	M8	0,50	18
180A (S13)	25	4	M8	0,50	18
210A (S13)	25	4	M8	0,50	18
300A (S14)	50	1	M8	0,50	18
350A (S14)	50	1	M8	0,50	18
400A (S14)	50	1	M8	0,50	18
450A (S14)	70	1/0	M8	0,50	18
500A (S14)	70	1/0	M8	0,50	18
800A (S17)	70	1/0	M8	0,50	18

5.4 Terminals Positions

Size S13 / S14

M1

Open and flip the cover



Size S17

Size S11



5.5 Power Terminals

Warning: Before connecting or disconnecting the unit check that power and control cables are isolated from voltage sources.

Terminal	Description
L1	Line Input Phase 1
L2	Line Input Phase 2
L3	Line Input Phase 3
T1	Load Output Phase 1
T2	Load Output Phase 2
T3	Load Output Phase 3

REVO-S 3PH
60-90A (S11)

REVO-S 3PH
120-210A (S13)

REVO-S 3PH
300A-500A (S14)

REVO-S 3PH
800A (S17)

5.5.1 Bar dimensions S14



3PH from 300 to 400A



3PH from 450 to 500A

Current	A	B	C	D	E	F	G	H	M
300A (S14)	71mm	60mm	45mm	57mm	30mm	-	350mm	174mm	M10
350A (S14)	71mm	60mm	45mm	57mm	30mm	-	350mm	174mm	M10
400A (S14)	71mm	60mm	45mm	57mm	30mm	-	350mm	174mm	M10
450A (S14)	54mm	76mm	21mm	37mm	66mm	35mm	390mm	165mm	M10
500A (S14)	54mm	76mm	21mm	37mm	66mm	35mm	390mm	165mm	M10

5.5.2 Bar dimensions S17 (800A)

Current	A	B	C	D	E	F	G	H	M
800A (S17)	71mm	60mm	45mm	57mm	30mm	-	350mm	174mm	M10



5.6 Control Terminals

Warning: Before connecting or disconnecting the unit check that power and control cables are isolated from voltage sources.

M1

Terminal	Description
1	NO - Normally Open contact alarm relay output (Thermal or SC/HB)
2	C - Common contact alarm relay output
3	NC - Normally Close contact alarm relay output (Thermal or SC/HB)
4	Not Connected
5	DI 2 - Enable Digital Input
6	DI 1 - Configurable Input
7	Not Connected
8	Not Connected
9	Output +10Vdc stabilized 1 mA MAX
10	0V GND
Terminal	**Description**
11	- Analog Input 1 (0-10Vdc/4-20mA Analog Setpoint)
12	+ Analog Input 1 (0-10Vdc/4-20mA Analog Setpoint)
13	COM I - Common Digital Input
14	Not Connected
15	Fan supply (230V Standard – 115 Option - for DC Fan Option +24Vdc)
16	Fan supply (230V Standard – 115 Option - for DC Fan Option -24Vdc)
17	Not Connected
18	Aux – Voltage Supply for electronic boards and synchronization (See order code for the Value)
19	Not Connected
20	Aux – Voltage Supply for electronic boards and synchronization (See order code for the Value)

M2

Terminal	Description
1	24Vdc power input
2	Slave Output
3	Retransmission Output
4	0V GND

5.7 Schematic

Caution: this procedure must be performed only by qualified persons.

Indicative connection diagrams. Refer to local regulations for proper system protection.



*

- In normal conditions (without alarm) and with auxiliary power supply, the contact to the terminals is Terminal 2-3 open / Terminal 2-1 closed (relay coil energized).
- In alarm condition or without auxiliary power supply the contact to the terminals is Terminal 2-3 closed / Terminal 2-1 open (relay coil not energized).

NOTE:

*1 The user installation must be protecting by electromagnetic circuit breaker or by fuse isolator. The Fuse must be branch circuit protection.

*3 For SSR input connection follow next page schematic.

5.7.1 SSR Control Input schematic

For SSR input follow the schematic below and configure Digital Input 1 as SSR input.



*** SSR Input:**
4 ÷ 30Vdc 5mA Max (ON ≥4Vdc OFF <1Vdc)
3HZ Max on time min. 100 ms

5.8 Connection Diagram for 3 phases

Caution: this procedure must be performed only by qualified persons.



Note: Aux Voltage and Load Voltage must be synchronized

X = not connected
*1 The user installation must be protecting by electromagnetic circuit breaker or by fuse isolator.
The Fuse must be branch circuit protection. For UL any listed UL branch circuit fuse would be acceptable as an external fuse, following national electric code guide for resistive heating of 125% load current rating to protect external wires.

Load Type



6 Led status and alarms

LED status

LED	STATUS	DESCRIPTION
EN	LED Flashing (-☀-)	Waiting for Enable Signal
	LED ON (■)	Enable Signal to terminal
ON	LED OFF (■)	Load is NOT powered
	LED ON (■)	Load is powered
SC	LED OFF (■)	Load OK
	LED ON (■)	SCR short circuit (only with HB option)
	LED Flashing (-☀-)	Enable contact open or Over temperature on heat sink
HB	LED OFF (■)	Load OK
	LED ON (■)	Load Fault (only with HB option)



Input type informations



Burst Firing informations



7 Heater Break alarm and SCR short circuit

(HB Option only)

Caution: to work properly the load must be powered at least about 160msec.

The Heater Break circuit read the load current with an Internal current transformer (C.T.).
Minimum current is 10% of the current transformer size.
If load current is below this value the Heater Break Alarm doesn't work properly.

7.1 Heater break Calibration procedure

An automatic function sets the Heater Break Alarm.

The auto setting function can be activated by pressing the keys F▲ + I■ simultaneously for 4 seconds.

The Heater Break calibration procedure is performed in this way:

- The Unit gives the maximum voltage output
- The leds light up in sequence until the procedure is completed
- The current and voltage value is stored in memory
- After about 15 second the unit comes back to the initial situation

If load resistance increase more than 20% (sensitivity 20%) the HB LED become ON and alarm relay change status.
If the unit is still in conduction with no input signal (ON LED OFF) it means that there is a short circuit on thyristors and SC LED become ON.
If the load has been changed the Heater Break calibration procedure must be done again.

The HB Alarm is detected with minimum ON time 100 ms

8 Input Setting

The Input type is already configured in line with customer requirements that are defined in the order code. However, if you need to to make changes you must follow the following procedure.



9 Burst Firing settings

The Burst Firing cycles is already configured in line with customer requirements that are defined in the Order Code. However, if you wish to change the Burst Firing cycles (es. from 4 to 8) you must follow the following procedure.



10 Firing type

Choose a correct firing type allows to optimize the thyristor unit for the installed load.
The firing type has already configured in line with customer requirements, Zero Crossing for SSR input and Burst firing for Analog Input.

Caution: this procedure must be performed only by qualified persons.

10.1 Zero Crossing

ZC firing mode is used with Logic Output from temperature controllers and the Thyristor operates like a contactor.
The Cycle time is performed by temperature controller. ZC minimizes interferences because the Thyristor unit switches ON-OFF at zero voltage.



10.2 Burst Firing

The Burst Firing is a burst of consecutive cycles, the consecutive cycles ON are selectable (4,8,16), with input signal equal at 50%.
Burst Firing is a method zero crossing that it reduces the electromagnetic interferences because the thyristor switches at zero voltage crossing.
The example shows a Burst firing set with 4 cycles.



11 Supply the electronic board

The REVO S thyristor unit, to work, requires a voltage supply for the electronic boards. The Max consumption is 10VA. The voltage supply for the electronic boards is configured in line with customer requirements that are defined in the Order Code. The Order Code is written on the identification label.

- **Warning:** Before connecting or disconnecting the unit check that power and control cables are isolated from voltage sources.
- **Specialised personnel only**

Terminal M1	Description
18	Voltage Supply for Electronic Boards (Auxiliary Voltage)
19	Not Used
20	Voltage Supply for Electronic Boards (Auxiliary Voltage)

If it is necessary to change the value of the auxiliary supply voltage, move the jumpers as shown in the table below.
The range of the auxiliary voltage that can be set depends on the transformer mounted on the board, see the ordering code on Digit 8 (see table).

Order Code	As ordered		Change to	
	Jumper JP1 + JP2 are linked		Link only Jumper JP3	
	Transformer range	Line voltage	Transformer range	Line voltage
RS3_ _ _-_**1**	90:135V	100/120V	180:265V	200/208/220/230/240
RS3_ _ _-_**2**	180:265V	200/208/220/230/240V	342:528V	380/400/415/440/480
RS3_ _ _-_**3**	238:330V	277V	540:759V	600/690
	Only Jumper JP3 is linked		Link Jumper JP1 + JP2	
RS3_ _ _-_**5**	342:528V	380/400/415/440/480V	180:265V	200/208/220/230/240V
RS3_ _ _-_**6**	540:759V	600V	238:330V	277V
RS3_ _ _-_**7**	540:759V	690V	238:330V	277V



- **Attention! never link all the jumpers JP1+JP2+JP3 at the same time or JP3 + any other jumper, JP3 must be always alone, follow only the configuration shown.**

12 Internal Fuse

The thyristor unit have internal fuse extrarapid at low I^2t for the thyristor protection of against the short-circuits. The Fuses must have I^2t 20% less than thyristor's I^2t. The warranty of thyristor is null if no proper fuses are used.

Size	200 kA_{RMS} Symmetrical A.I.C.					Quantity for each phase
	Fuse CODE	Total Current (A_{RMS})	Fuse I^2t value Suggested A2s (at 500V)*	Fuse I^2t value Suggested A2s (at 660V)	Vac	
60A (S11)	FU2028220.160	160	15400	16940	690	1
90A (S11)	FU2028220.160	160	15400	16940	690	1
120A (S13)	FU2055920.160	160	15400	16940	690	1
150A (S13)	FU2055920.200	200	25000	27500	690	1
180A (S13)	FU2055920.250	250	44000	48400	690	1
210A (S13)	FU2055920.315	315	77000	84700	690	1
300A (S14)	FUFMM400	400	72500	79750	690	1
350A (s14)	FUFMM550	550	150500	215000	690	1
400A (S14)	FUFMM550	550	215000	236500	690	1
450A (S14)	FUFMM700	700	420000	462000	690	1
500A (S14)	FUFMM700	700	420000	462000	690	1
800A (S17) until december 2024	FU2055920.250	1000	352000	387200	690	4
800A (S17) from january 2025	FUFMM550	1100	602000	860000	690	2



*I^2t are multiplied for K value in function of Vac at 690V K is equal to 1,1 (ex:15400 X 1,1 = 16940). At 660Vac K is equal to 1.

Fuses replacement: Open the cover and remove the screws, then replace it with the correct fuse, use the screws with a proper suggested torque indicated below

TYPE	Screw	Torque Lb-in (N-m)
60A-210A	M6	44.2 (5.0)
300A-800A	M8	133.7(15.0)

Caution: High speed fuses are used only for the thyristor protection and can not be used to protect the installation.

Caution: The warranty of thyristor is null if no proper fuses are used. See tab.

Warning: When it is supply, the Thyristor unit is subject to dangerous voltage, don't open the Fuse-holder module and don't touch the electric equipments.

CD Automation S.r.l.
Via Picasso, 34/36 - 20025 Legnano (MI) - Italy
Tel. +39 0331 577479 - Fax +39 0331 579479
E-mail: info@cdautomation.com - Web: www.cdautomation.com