

# 3 PHASE SCR BRIDGE

	1	2	3	4	5	6		7	8	9	10	11	12	13	14	15	16
<b>ORDERING CODE</b>	<b>B</b>	<b>T</b>	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-

<b>CURRENT</b>	3	4	5	6	
<b>description</b>	<b>code</b>				<b>note</b>
1000A	1	0	0	0	
1300A	1	3	0	0	
1600A	1	6	0	0	
1800A	1	8	0	0	
2000A	2	0	0	0	
2200A	2	2	0	0	
2400A	2	4	0	0	
<b>MAX VOLTAGE</b>	7				
<b>description</b>	<b>code</b>				<b>note</b>
480V	4				
600V	6				
690V	7				
<b>VOLTAGE SUPPLY AUX.</b>	8				
<b>description</b>	<b>code</b>				<b>note</b>
110V	1				
220V	2				
<b>INPUT</b>	9				
<b>description</b>	<b>code</b>				<b>note</b>
0:10V	V				
4:20 mA	A				
<b>FIRING</b>	10				
<b>description</b>	<b>code</b>				<b>note</b>
Without Control Board	0				
Control Board Phase Angle	P				

<b>CONTROL MODE</b>	11	
<b>description</b>	<b>code</b>	<b>note</b>
Voltage	U	
Current	I	
Power	W	
<b>OPTION &amp; FUSES</b>	12	
<b>description</b>	<b>code</b>	<b>note</b>
Fixed fuses standard	F	
Fixed fuses + CT	Y	
<b>FAN VOLTAGE</b>	13	
<b>description</b>	<b>code</b>	<b>note</b>
Fan 110V	1	
Fan 220V Standard	2	
<b>APPROVALS</b>	14	
<b>description</b>	<b>code</b>	<b>note</b>
CE EMC	0	
<b>MANUAL</b>	15	
<b>description</b>	<b>code</b>	<b>note</b>
None	0	
Italian	1	
English	2	
German	3	
French	4	
<b>LOAD TYPE</b>	16	
<b>description</b>	<b>code</b>	<b>note</b>
Resistive Load	1	
Inductive Load	2	