

# 3 PHASE SCR BRIDGE

	1	2	3	4	5	6		7	8	9	10	11	12	13	14	15	16
<b>ORDERING CODE</b>	B	T	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-

CURRENT	3	4	5	6	
description	code				note
1000A	1	0	0	0	
1300A	1	3	0	0	
1600A	1	6	0	0	
1800A	1	8	0	0	
2000A	2	0	0	0	
2200A	2	2	0	0	
2500A	2	5	0	0	
MAX VOLTAGE	7				
description	code				note
480V	4				
600V	6				
690V	7				
VOLTAGE SUPPLY AUX.	8				
description	code				note
110V	1				
220V	2				
INPUT	9				
description	code				note
0:10V	V				
4:20 mA	A				
FIRING	10				
description	code				note
Without Control Board	0				
Control Board Phase Angle	P				

CONTROL MODE	11	
description	code	note
Voltage	U	
Current	I	
Power	W	
OPTION & FUSES	12	
description	code	note
Fixed fuses + CT	Y	
FAN VOLTAGE	13	
description	code	note
Fan 110V	1	
Fan 220V Standard	2	
APPROVALS	14	
description	code	note
CE EMC	0	
MANUAL	15	
description	code	note
None	0	
Italian	1	
English	2	
German	3	
French	4	
LOAD TYPE	16	
description	code	note
Resistive Load	1	
Inductive Load	2	