

<b>REVO PB</b>	<b>1</b>	<b>2</b>	<b>3</b>	<b>4</b>	<b>5</b>	<b>6</b>		<b>7</b>	<b>8</b>	<b>9</b>	<b>10</b>	<b>11</b>	<b>12</b>	<b>13</b>	<b>14</b>	<b>15</b>	<b>16</b>
<b>ORDER CODE</b>	<b>P</b>	<b>B</b>	<b>3</b>	-	-	-	-	-	-	-	-	-	-	-	-	-	-

<b>CURRENT</b>	<b>4</b>	<b>5</b>	<b>6</b>
description	code		
35A	0	3	5
50A	0	5	0
75A	0	7	5
90A	0	9	0

<b>MAX VOLTAGE</b>	<b>7</b>
description	code
480V	4
600V	6

<b>AUXILIARY VOLTAGE</b>	<b>8</b>
description	code
24Vdc	4

<b>INPUT</b>	<b>9</b>
description	code
RS485 Modbus RTU Communication and DI	0

<b>FIRING</b>	<b>10</b>
description	code
Half cycle	0
Single cycle	1

<b>CONTROL MODE</b>	<b>11</b>
description	code
No Feed-back	1
Power Vxl	2

<b>OPTION</b>	<b>12</b>
description	code
Display, Heater Break alarm	0

<b>FAN VOLTAGE</b>	<b>13</b>
description	code
24Vdc fan	3

<b>APPROVALS</b>	<b>14</b>
description	code
CE EMC for European market	0

<b>LOAD TYPE</b>	<b>15</b>
description	code
1PH Normal resistance	0
1PH IRSW Infrared Short Wave	1

<b>VERSION</b>	<b>16</b>
description	code
Standard version	0

## COMMUNICATION MODULES

	<b>1</b>	<b>2</b>		<b>3</b>	<b>4</b>	<b>5</b>	<b>6</b>	<b>7</b>		<b>8</b>	<b>9</b>	<b>10</b>		<b>11</b>	<b>12</b>	<b>13</b>	<b>14</b>	<b>15</b>	<b>16</b>
<b>ORDER CODE</b>	<b>T</b>	<b>U</b>	-	<b>R</b>	<b>S</b>	<b>4</b>	<b>8</b>	<b>5</b>	-	-	-	-	-	-	-	-	-	-	-

<b>COMMUNICATION</b>				<b>3</b>	<b>4</b>	<b>5</b>	<b>6</b>	<b>7</b>
Modbus RTU				R	S	4	8	5

<b>FIELD BUS, COMMUNICATION OR OTHER FUNCTIONS</b>		<b>8</b>	<b>9</b>	<b>10</b>		<b>11</b>	<b>12</b>	<b>13</b>	<b>14</b>	<b>15</b>	<b>16</b>
Modbus TCP Protocol Converter	-	T	C	P	-	3	5	8	0	M	B
Modbus TCP, Modbus Slave, IO, Data Logger, Logic	-	E	T	H	-	I	O	D	L	0	0
Profinet	-	P	N	T	-	0	6	7	6	0	2
Ethernet IP	-	E	I	P	-	0	6	7	5	9	1
RS232	-	2	3	2	-	3	5	8	0	2	W