RPC412 / RPC424 - up to 24 1PH channel balanced on the three phases Connection Phase to Neutral

	1	2	3	4	5	6		7	8	9	10	11	12	13	14	15	16
ORDER CODE	R	Р	С	-	-	-	-	-	-	-	-	-	-	-	-	-	-

CONNECTION	4	
description	code	note
F1-N; F2-N; F3-N All the 1PH channel can be balanced on the three phases - Phase to Neutral	4	

Firing	12	
description	code	note
Half Cycle at 50% power demand	1	
One Cycle at 50% power demand	2	

CHANNELS	5	6	
description	со	de	note
12 channel REVO PC to drive 12 REVOS-1PH Max with Random Firing	1	2	
24 channel REVO PC to drive 24 REVOS-1PH Max with Random Firing	2	4	

FEED BACK (Control Mode)	13	
description	code	note
No Feed Back	1	
Power	2	

One Current Sensor Input for each channel	7	8	9	
description		code		note
Current Sensor is included and integrated with REVO S 1PH units with "Y" Option	0	0	0	

Approvals	14	
description	code	note
CE EMC	1	
CE + cUL (pending)	L	

Communication	10	
description	code	note
N°1 Ethernet Port, Modbus® TCP and n°3 Modbus® RTU	1	
N*1 Profibus-DP® Port (with external communication module)	4	
N°1 Ethernet Port ProfiNet®	5	

Manual	15	
description	code	note
None	0	
Italian	1	
English	2	
German	3	
French	4	

Aux Voltage to be coupled with an external transformer	11	
description	code	note
24Vdc	4	

Version	16	
description	code	note
Version 2	2	